



1. Never wire more than 1 motor to a SPDT keyswitch!

2. The motor wires are called "Direction 1" or Direction "2" rather than "up" or "down". Depending on whether the motor is located on the right or left side of the rollshutter, its black wire will be either powering the "up" or "down" direction with the red wire always powering the opposite direction.

3. If after completion of the wiring you discover that the rollshutter runs down when the switch is moved to the intended up, then simply interchange the motor's black wire with the motor's red wire.

4. Always use at least 14 gauge solid copper wire. Some jurisdictions require 12 gauge wire. All wiring must be performed by a certified electrician. Consult your local electrical code.