



You asked, we listened!

After multiple requests, and careful consideration, we have decided to change the way we package our roll shutter curtains.

Currently, you have been receiving curtains rolled up with the top slat that connects to the axle/shaft exposed.

Starting March 18th, we will be rolling the curtains in the opposite direction.

This means the bottom bar/ endslat will be on the outer edge of the roll. This will enable you to be able to take the bottom bar, feed it up and over the axle, and insert it into the guide rails.

Extra foam material will be provided within the curtain packaging that can be removed and placed over the axel to protect the curtain from scratching while you slowly unroll the curtain into the rails.

Please see Page 11 of our installation manual for complete instructions. **(Reverse Side)**

We hope this change will be received well and provide you with an easier way to load the curtains.

Thank you,

Ultra-Lite Shutters Team

Installing Shutter Curtain

- ⚠ ALWAYS USE AS MANY PEOPLE AS NECESSARY TO AVOID INJURY OR PRODUCT DAMAGE
- ⚠ BE SAFE AT ALL TIMES AND NEVR STAND IN THE OPENING OR UNDER THE SHUTTER
- 💡 Light weight curtains will come pre-rolled inside the hood.

1. After successfully mounting the hood assembly, you are ready to install the curtain.
 - ❖ Lightweight curtains will normally come installed inside the hood for easier setup. You can temporarily wire the motor to drop the curtain and complete the wiring and then complete the limit settings.
2. For heavier curtains, you will receive boxes with the curtain separated.
 - ❖ If you receive your curtain in two or more sections, follow these steps. Once the first section is draped over the axle, with assistance, slide on the bottom portion, attach the slat stop on the ends and continue.

3. Out of the packaging, your curtain should be rolled so that the bottom bar/end slat is on the outer edge of the roll.

4. If you would prefer, you may use some of the packaging material and drape it over the axle to avoid scratching the slats in the following steps.
5. With assistance, take the bottom bar of the curtain and feed it over the axle and into the guide rail channels.
6. Slowly unroll, and while supporting the bottom bar as it drops, continue to feed the curtain into the guide rail channels.
7. Before the last slat is inside the hood, slide on your Anti-Push-Up Curtain Attachments.
8. Once the curtain is fully resting, separate the Curtain Attachments 30-50 cm (12-14") and fasten them to the axle, following the directions that are included.
9. Ensure that all fasteners are secure, and you should also confirm that if a Shaft Bolt is used in your Roll Shutter, you have secured it and used Loctite to secure the set-screw.
10. Use the packaged pop-rivets to fasten the anti-pushup curtain hangers when installing directly over the motor. This will ensure that nothing can come into contact with the motor and cause damage during operation.
11. If you are using T-Hangers (Steel Strips) you must ensure that they are securely fastened to the axle.

